HST-D107

SERVICE MANUAL

AEP Model
UK Model

• HST-D107 are the STEREO DECK RECEIVER in LBT-D107

SPECIFICATIONS

Tuner

System: FM stereo
FM/AM superheterodyne tuner

FM tuner section
- Tuning range: 87.5 to 108 MHz
- Antenna: 75 ohms unbalanced
- Intermediate frequency: 10.7 MHz

MW/LW tuner section
- Tuning range: MW: 522 to 1,611 kHz (Italian model)
  531 to 1,602 kHz (other models)
  LW: 144 to 288 kHz (Italian model)
  153 to 279 kHz (other models)
- Antenna: AM loop antenna
  External antenna terminal
- Intermediate frequency: 450 kHz

Amplifier

DIN power output: 20 W + 20 W (6 ohms, at 1 kHz)
Continuous RMS power output: 23 W + 23 W (6 ohms, at 1 kHz, 5% THD)
Music power output: 40 W + 40 W (6 ohms)

Input	Jack type	Sensitivity	Impedance
CD IN	Phono	300 mV	47 kohms
VIDEO IN	Phono	300 mV	47 kohms
PHONO IN	Phono	3 mV	47 kohms

Output	Jack type	Impedance
SURROUND SPEAKER	Phono	*Accepts speakers of 16 ohms*
HEADPHONES	Stereophone	Accepts headphones of 8 ohms or more

Frequency response: CD: 15 Hz to 50 kHz $^{+0}_{-3}$ dB

Model Name Using Similar Mechanism	HST-D105
Tape Transport Mechanism Type	TCM-180VW-H7

Cassette deck

Recording system: 4-track 2-channel stereo
Frequency response: DOLBY NR OFF
With Type II cassette (Sony UX-S)
40 Hz to 14 kHz (±3 dB)
With Type I cassette (Sony HF-S)
40 Hz to 13 kHz (±3 dB)
Wow and flutter: W.PEAK ±0.2% (DIN)

General

Power requirements: 220 – 230 V AC, 50/60 Hz
Power consumption: 60 W
Weight: Approx. 6.7 kg
Dimensions: Approx. 355 × 290 × 325 mm (w/h/d, including projections)

Supplied accessories

45-rpm adaptor (1) (excluding for HST model)
Remote commander RM-S171 (1)
FM wire antenna (1) (excluding German model)
AM loop antenna (1)
Batteries Sony SUM-3 (NS) (2)

Design and specifications subject to change without notice.

Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
"DOLBY" and the double-D symbol DD are trademarks of Dolby Laboratories Licensing Corporation.

MICROFILM

COMPACT Hi-Fi STEREO SYSTEM

SONY®

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety check before releasing the set to the customer:
Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampers). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)



Fig. A. Using an AC voltmeter to check AC leakage.

TABLE OF CONTENTS

Section	Title	Page
SECTION 1.	GENERAL	3
SECTION 2.	ADJUSTMENTS	4
SECTION 3.	DIAGRAMS	
3-1.	Block Diagram	7
3-2.	Circuit Boards Location	9
3-3.	Printed Wiring Boards — Audio Section —	10
3-4.	Schematic Diagrams — Audio Section —	15
3-5.	Schematic Diagrams — Panel Section —	18
3-6.	Schematic Diagrams — Tuner Section —	21
3-7.	Schematic Diagrams — TC Section —	24
3-8.	Printed Wiring Boards — TC Section —	27
3-9.	Semiconductor Lead Layouts	29
SECTION 4.	EXPLODED VIEWS	
4-1.	Cabinet Section	30
4-2.	Front Panel Section	31
4-3.	Mechanism-1 Section	32
4-4.	Mechanism-2 Section	33
4-5.	Mechanism-3 Section	34
SECTION 5.	ELECTRICAL PARTS LIST	35

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK ⚠ OR DOTTED LINE WITH MARK ⚠ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SECTION 1
GENERAL

This section is extracted from instruction manual.



Location of Controls

Refer to the pages indicated in ( )for details.

Tuner

1 ST/MUTE button (20)
2 MEMORY button (22)
3 Remote sensor
4 POWER switch (14)
5 Display window
6 SHIFT button (22)
7 BAND SELECT button (20)
8 Buttons for storing station frequencies (22)
9 DUAL MODE TUNING buttons (20, 22)

Amplifier

10 GRAPHIC EQUALIZER controls (16)
11 HEADPHONES jack
12 Function indicators
13 Function selectors (VIDEO/TAPE/CD/TUNER/PHONO)
14 VOL (volume) control (16)
15 SURROUND control (16)
16 DBFB (dynamic bass feedback) control (16)
17 BALANCE control (16)

Cassette Deck

18 Cassette holders
19 Tape operation buttons (24)
◀◀ Leftward fast winding
▶▶ Rightward fast winding
▶ Forward play
■ ⏏ Stop/eject
❚❚ PAUSE Pause
● REC Record
20 TAPE SELECT button (24, 26, 30)
21 DUBBING SPEED button (30)
22 DOLBY NR (noise reduction) button (24, 26)

SECTION 2
ADJUSTMENTS

2-1. MECHANICAL ADJUSTMENTS

1. Clean the following parts with a denatured alcohol-moistened swab:
   record/playback heads — pinch rollers
   erase heads — rubber belts
   capstan — idlers
2. Demagnetize the record/playback head with a head demagnetizer.
3. Do not use a magnetized screwdriver for the adjustments.
4. After the adjustments, apply suitable locking compound to the parts adjusted.
5. The adjustments should be performed with the rated power supply voltage unless otherwise noted.

Torque Measurement

Torque	Torque meter	Meter reading
FWD	CQ-102C	30—70g·cm (0.42—0.97oz·inch)
FWD Back tension	CQ-102C	1.5—5.5g·cm (0.020—0.076oz·inch)
FF. REW	CQ-201B	63g·cm or more (0.87oz·inch)

2-2. ELECTRICAL ADJUSTMENTS

0dB=0.775V (AF)
0dB=0.1μV (RF)

CASSETTE DECK SECTION

1. Demagnetize the record/playback head with a head demagnetizer. (Do not bring the head demagnetizer close to the erase head.)
2. Do not use a magnetized screwdriver for the adjustments.
3. After the adjustments, apply suitable locking compound to the parts adjusted.
4. The adjustments should be performed with the rated power supply voltage unless otherwise noted.
5. The adjustments should be performed in the order given in this service manual. (As a general rule, playback circuit adjustment should be completed before performing recording circuit adjustment.)
6. The adjustments should be performed for both L-CH and R-CH.

• Switches and controls should be set as follows unless otherwise specified.
DOLBY NR switch: OFF
TAPE SELECT switch: TYPE I

Type	Signal	Used for
P-4-A100	10kHz, −10dB	Azimath Adjustment
P-4-L300	315Hz, 0dB	PB Level Adjustment
WS-48B	3kHz, 0dB	Tape Speed Adjustment

Record/Playback Head Azimuth Adjustment

Note: Perform this adjustments for both decks.

Procedure:

1. Mode: FWD playback



2. Turn the adjustment screw and check output peaks. If the peaks do not match for L-CH and R-CH, turn the adjustment screw so that outputs match within 1 dB of peak.





3. After the adjustments, apply suitable locking compound to the parts adjusted.

Adjustment Location:



Tape Speed Adjustment

Procedure :

Mode : playback



- High speed adjustment
  1. Short pin CN407. Then at HIGH speed mode.
  2. Adjust RV504 so that the frequency counter reads 6000 ± 20Hz.
     (Must be first Adjustment B deck)
- NORMAL speed adjustment
  1. Remove the short pin from CN407. Then at NORMAL speed mode.
  2. Adjust RV505 so that the frequency counter reads 3000 ± 10Hz.

Abjustment Location: TC MAIN board



Playback Level Adjustment

Procedure :

Mode : FWD playback



DECK-A side RV400(L-CH), RV500(R-CH)
DECK-B side RV401(L-CH), RV501(R-CH)
so that the limits below are satisfied.

Adjustable limits :

CN405 level: 461.6 — 411.4mV(−4.5 — −5.5dB)
level difference between the channels : within 1.0dB
(See page 6 for Adjustment Location)

Record BIAS Current Adjustment

Procedure :

1. Mode : record



2. Mode : Playback



(1) Supply a 43.6mV(−25dB) signal (315Hz) from the CD IN. Adjust the VOLUME control so that a 24.5mV(−30dB) signal is output to the headphones terminal.
(2) Insert alignment tape CS-122 into deck B and put the set into the REC mode.
(3) Adjust the signal frequency to 10kHz.
(4) Put the set into the PB mode and adjust RV403(L CH) and RV503(R CH) in the REC mode so that the level difference between 315Hz and 10kHz is within 0±0.5dB.
(5) Repeatedly put the set into the REC and PB modes two to four times and adjust the bias.

Adjustable limits :

The HEADPHONES level of 10kHz signal relative to that of 315Hz : 0dB±0.5dB

Record Level Adjustment

Setting :

TAPE SELECT : TYPE I

Procedure :

1. Mode : record



2. Mode : playback



(1) Supply a 43.6mV(−25dB) signal (315Hz) from the CD terminal.
(2) Insert alignment tape CS-122 into deck B and record the signal. Then playback the recorded portion of the tape and adjust RV402(L-CH) and RV502(R-CH) so that the 43.6mV (−25dB) signal output is obtained at CN405 terminal.

Adjustable limits :

CN405 level : 46.2 — 41.1mV(−24.5 — −25.5dB)

TUNER SECTION

As FM FRONT-END FE301 is difficult to repair if faulty, replace it with new one.

FM NULL Adjustment



Procedure :

1. Tune the set to 98 MHz.
2. Adjust T301 for 0V reading on the VTVM.

Adjustment Location :

MAIN BOARD (Component side)



FM Tuned Level Adjustment

Setting:

STEREO/MUTE : OFF



Procedure :

1. Tune the set to 98 MHz.
2. Adjust RV302 to the point where "TUNED" FL601 just turns light.

• AM SECTION



AM Tuned Level Adjustment

• AM BAND

1. Set loop antenna input level to 2.5mV (50 dBμ/m) and nc
   tuned light should not on.
2. Tune the set to 1490kHz.
3. Adjust RV301 to the point where "TUNED" sign on FL6
   turns light.

Adjustment Location :

TC MAIN BOARD (Component side)



from the CD ter-

3 and record the
of the tape and
that the 43.6mV
terminal.

IB)

to repair if

VTVM

ninal(75Ω)

VM.

FM Tuned Level Adjustment

Setting:

STEREO/MUTE : OFF



Carrier frequency: 98MHz
Output level: 0.018mV(25dBμ)
Modulation: 1kHz, 75kHz deviation

Procedure:

1. Tune the set to 98 MHz.
2. Adjust RV302 to the point where "TUNED" sign on FL601 just turns light.

• AM SECTION



Carrier frequency: 216kHz
Modulation: 400Hz, 30% modulation

AM Tuned Level Adjustment

• AM BAND

1. Set loop antenna input level to 2.5mV (50 dBμ/m) and no signal tuned light should not on.
2. Tune the set to 1490kHz.
3. Adjust RV301 to the point where "TUNED" sign on FL601 just turns light.

Adjustment Location :

TC MAIN BOARD (Component side)


RV400 : Playback Level Adjustment (DECK-A, L-CH)
RV500 : Playback Level Adjustment (DECK-A, R-CH)
RV401 : Playback Level Adjustment (DECK-B, L-CH)
RV501 : Playback Level Adjustment (DECK-B, R-CH)
RV504 : Tape Speed Adjustment (High)
RV505 : Tape Speed Adjustment (Normal)
CN407 : Tape Speed Adjustment
CN405
RV402 : Record Level Adjustment (L-CH)
RV502 : Record Level Adjustment (R-CH)
RV403 : Record BIAS Current Adjustment (L-CH)
RV503 : Record BIAS Current Adjustment (R-CH)

SECTION 3
DIAGRAMS

3-1. BLOCK DIAGRAM





3-2. CIRCUIT BOARDS LOCATION



3-3. PRINTED WIRING BOARDS –AUDIO Section–

· See page 29 for semiconductor lead layouts.

· See page 9 for circuit boards location.

● Semiconductor Location

Ref. No.	Location	Ref. No.	Location
D351	F-18	IC1103	G-4
D601	D-5	IC1104	G-7
D602	E-10	IC1201	C-15
D603	D-5	IC1202	F-27
D604	E-10	IC1303	H-26
D611	F-8	IC1304	G-24
D612	F-8	IC1305	F-26
D613	F-8	IC1306	B-24
D614	F-8		
D618	G-5	Q301	D-20
D625	F-9	Q302	D-20
D641	E-9	Q303	D-20
D1130	H-10	Q304	E-20
D1131	H-8	Q305	I-20
D1132	H-6	Q306	I-20
D1133	H-7	Q307	H-21
D1134	H-9	Q308	H-20
D1145	G-2	Q309	H-21
D1151	G-7	Q351	D-19
D1152	G-7	Q352	C-19
D1153	G-6	Q353	D-19
D1201	C-16	Q354	E-19
D1202	D-27	Q355	E-18
D1203	D-27	Q356	E-19
D1204	F-27	Q501	F-18
D1251	E-16	Q502	F-18
D1302	C-26	Q521	B-21
D1303	C-25	Q522	B-22
D1304	C-24	Q531	C-22
D1305	C-25	Q532	C-22
D1306	C-25	Q601	D-5
D1307	A-30	Q602	F-13
D1309	B-30	Q1001	I-6
D1311	A-30	Q1002	G-22
D1318	B-25	Q1101	I-6
D1319	B-25	Q1102	H-4
D1321	H-26	Q1121	G-8
D1323	D-25	Q1122	G-6
D1324	D-25	Q1136	G-8
D1341	H-26	Q1138	G-8
D1368	B-25	Q1141	G-5
D1369	B-25	Q1143	G-6
		Q1144	G-6
IC301	G-19	Q1145	G-6
IC501	E-21	Q1151	I-7
IC601	E-8	Q1152	G-4
IC602	F-14	Q1201	C-16
IC1001	C-23	Q1202	F-16
IC1002	E-23	Q1203	F-16
IC1003	I-23	Q1204	F-27
IC1004	G-23	Q1251	F-16
IC1101	I-9	Q1301	A-30
IC1102	F-11	Q1302	H-25

Note:

● ○—— : parts extracted from the component side.

IT:Italian



FL601


F F NP P16 P4 P5 P3 P6 P2 P1 P15 P10 P9 P8 P11 P12 P13 P14 NC NC NC NC NC 8G 7G 6G 5G 4G 3G 2G 1G NP F F
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35
8G 7G 6G 5G 4G 3G 2G 1G
ONCE DAILY
ON OFF
SLEEP
AUTO
MUTING
TUNED
STEREO
MEMORY
PRESET
kHz
MHz
DP.1
DP.2
RED

【POWER AMP BOARD】





【MAIN BOARD】






TM301
ANTENNA
FM 75Ω COAXIAL
AM
CN1002 PHONO IN
CN1301 FOR ONLY PS-LX49P
CN1001 (1/2) CD IN
CN1001 (1/2) VIDEO IN
CN1201 SPEAKER IMPEDANCE USE 6—16Ω
CN1202 SURROUND SPEAKER IMPEDANCE USE 16Ω
FE301 FM FRONT END
IC1001
IC1002
IC1003
IC1004
IC1301
IC1303
IC1304
IC1305
IC1306
IC501
IC1202
Q1001
Q1002
Q1204
Q1302
Q301
Q302
Q303
Q304
Q305
Q306
Q307
Q308
Q309
Q351
Q352
Q353
Q354
Q356
Q501
Q502
Q521
Q522
Q531
Q532
D1202
D1203
D1204
D1302
D1303
D1304
D1305
D1306
D1307
D1308
D1309
D1311
D1319
D1321
D1323
D1324
D1341
D1368
D1369
RY1201
XT501
TP1
CN1205
CN1206
CN1211
CN1212
CN1301
CN1302
CN1303
CN1204
CN1811
No.704
No.705
AEP,UK
UW104
LPF301
LPF302
IFT301
T301
S1301 POWER
TO TC MAIN BOARD CN411
TO TC MAIN BOARD CN410
1-641-704-11


【POWER BOARD】
CN1302
CN1301
D1307
D1309
D1311
F1302 T3.15A
F1303 T2.0A
F1304 T2.0A
F1307 T3.15A
T1301 POWER TRANSFORMER
BLU
BRN
BRN
BRN
CNP1301 AC IN
S1301 POWER
1-641-708-11

3-4. SCHEMATIC DIAGRAMS –AUDIO Section–





IC1202 μPC1237HA



Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4 W or less unless otherwise specified.
- △ : internal component.
- ⊣▭⊢ : nonflammable resistor.

Note: The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.

- ▬▬ : B+ Line
- ▬ ▬ : B− Line
- ▭ : adjustment for repair.
- Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions.
- Voltages are taken with a VOM (Input Impedance 10MΩ). Voltage variations may be noted due to normal production tolerances.
- ⇨ : FM ⇦ : PB (DECK A)

IT: Italian

3-5. SCHEMATIC DIAGRAMS –PANEL Section–

· See page 17 for note.





● IC Block Diagrams

IC301 LA1851N



IC501 LC7218



3-6. SCHEMATIC DIAGRAMS TUNER Section–

· See page 17 for note.



IT

TM301
ANTENNA
FM 75Ω
AM

FE301
ANT IN | GND | AGC | GND | VT | GND | IF OUT | +B | GND | F OUT

Q301 2SC2669-0Y FM IF AMP
Q302 2SC2669-0Y
Q303 2SC2669-0Y FM IF AMP
Q304 2SC2669-0Y

R313 100
CF301 MS
CF302 MS
CF303 MS
R303 330
R305 330
R306 27k
R308 330
R310 330
R311 27k
R304 18k
R307 560
C306 0.01
R309 18k
R312 820
C308 0.01
C301 0.01
R315 33k
R314 47k
C302 47 16V
C303 0.01
R302 100
R301 47
C305 0.01
C307 0.01
C309 0.01

AM TUNED

IFT301
C330 0.01
4.7mH
C328 0.1 50V
C327 0.01
RV301 22k
C326 10 50V
R328 47k
C329 4.7 100V

IC301
AM RF/OSC/MIX/IF DET
FM DET/MPX

IC301 LA1851N
V-REF | FM-AFC | AM-RF-IN | AM-MIX | AGC | AM-IF | ST-LED | TU-LED | TU-ST-RESET | IF-BUFF | AM/FM | MUTE | AM-SD-ADJ
VCC | AM-DET-OUT | FM-DET-OUT | DET | SEP. | L | R

R318 33k
C315 0.0068
T301
R319 8.2k
C318 1.50V
R320 18k
C321 0.47 50V
C322 0.1 50V
CF304
R321 3.3k
C320 1.50V
R322 10k
C323 0.0068
C324 0.0068
R323
R327 47k
C325 47 25V
R326 270
C313 3.3 100V
C314 0.01
C336 0.001
C316 100p
T302
C317 680p
Q306 DTA114ES VCO SWITCH
Q305 DTC114ES
R324 10k
R325 10k
C335 0.01
AEP,UK:1.2k
IT:1k
Q307 DTC114ES MUTING

R331 330k
R333 2.2k
C343 3.3 100V
LPF301
C341 3.3 100V
Q308 2SC2785- HFE BUFFER
R335 1.8k
C345 0.0022
R337 5.6k
C342 3.3 100V
R332 330k
R334 2.2k
C344 3.3 100V
LPF302
Q309 2SC2785- HFE BUFFER
R336 1.8k
C346 0.0022
R338 5.6k

Q501, 502 FM SWITCH
Q502 DTA114ES
Q501 DTC114ES
R510 47
C503 47 25V

IT C530 0.01

CL | DI | DO | CE | GND | GND | RESET | 5V | MUTING | TUNED | STEREO
(SD) (SI)
F TO PANEL BOARD CN601

GND | RESET | 5V | 13V | R CH | GND | L CH
C TO MAIN BOARD (2/2)

3-7. SCHEMATIC DIAGRAMS –TC Section–

· See page 17 for note.



CN411
R417 47k
R517 47k
R418 2k
R518 2k
REC L
REC R
PB R
GND
PB L
TO MAIN BOARD (2/2) CN1212

IC404
CXA1198AP
REC EQ AMP

	I Nor	II Nor	I High	II High
	R430 75k	R436 47k	R442 33k	R448 43k
	R431 33k	R437 47k	R443 36k	R449 51k
	R432 36k	R438 62k	R444 22k	R450 36k
	R433 150k	R439 82k	R445 62k	R451 51k
	R434 82k	R440 130k	R446 56k	R452 47k
	R435 150k	R441 130k	R447 150k	R453 120k

R519 10k
C515 2.2 100V
R520 2.2k
R522 1k
R422 1k
C516 4.7 100V
R521 10k
R523 3.4 4.7k
Q502
R524 6.8k
C517 0.47 50V
R525 2.7k
RV502 10k
Q503
R526 4.7k
R527 100k
C518 10 50V
R428 24k
IC404
C418 10 50V
Q403
R426 4.7k
RV402 10k
R424 6.8k
Q402
R423 3.4 4.7k
C470.47 50V
R425 2.7k
R421 10k
CN 405
C415 2.2 100V
R419 10k
C416 4.7 100V
R420 2.2k
R577 100k
R571 100k
Q402,502 2SC2785-HFE MUTING
R427 100k
C419 10 50V
Q403,503 2SC2785-HFE REC MUTING
C420 10 50V
C520 10 50V
C701 1 100V
R701 1k
S701-3 DOLBY NR OFF → ON
R429 12k
R529 12k
S701-1 TAPE SELECTOR TYPE I → TYPE II (120Ω) (70Ω)
R707 3.3k
R703 3.9k
R702 47k
Q702
Q701
R706 820
Q703
Q701-703 DTC144ES EQ SWITCH
R559 22k
R705 2.2k
R704 6.8k
S701-2 DUBBING SPEED NORMAL → HIGH
【SW BOARD】
IC515
M5F7807L
C540 470 10V
C560 470 10V
Q511
Q511 DTA144ES MUTING
Q512 DTC144ES H/L SWITCH
CN407
-7V
IC516
M5F7907L
TO MAIN BOARD (2/2) CN1211
CN410

● IC Block Diagrams

IC403 CXA1100AP



IC404 CXA1198AP



3-8. PRINTED WIRING BOARDS –TC Section–

· See page 9 for circuit boards location.

● **Semiconductor Location**

Ref. No.	Location
D500	B-3
D501	B-7
D502	B-7
D503	D-3
D504	D-3
D505	D-3
D506	C-3
D507	B-3
IC400	B-11
IC401	B-9
IC402	B-10
IC403	D-10
IC404	C-8
IC501	D-3
IC502	C-3
IC503	B-3
IC515	C-2
IC516	D-2
Q400	D-11
Q401	C-10
Q402	D-8
Q403	E-7
Q500	C-11
Q502	D-8
Q503	E-7
Q504	B-5
Q505	B-5
Q506	B-4
Q507	B-4
Q508	B-8
Q509	D-3
Q511	C-3
Q512	D-4
Q701	H-3
Q702	H-2
Q703	H-3







Note:

- ○—— : parts extracted from the component side.
- ● : Through hole.
- ▒▒ : Pattern on the side which is seen.
- ▒▒ : Pattern of the rear side.
- ▭ : Printed resistor from the rear side.

IT:Italian

3-9. SEMICONDUCTOR LEAD LAYOUTS

L78MR06



LC7218



M5F7807L
M5F7907L
TA7812S



STK4122MK2



(Making side View)

μPC1237HA



2SA1175-HFE
2SC2785-HFE



2SB1094-LK
2SC1815-Y
2SD2012



2SC1841-PAFAEA



2SC2669-OY
2SC3622A-LK
DTA114ES
DTA124ES
DTA144ES
DTC114ES
DTC124ES
DTC144ES



2SC3112-B
2SC945-P

2SK246-GR3



11ES2
1N4148M
UZ-3.9BSB
UZL-12M3
UZL-33L
UZL-5.6B



SEL1210S



SEL2210S-D



PBA-402



SECTION 4
EXPLODED VIEWS

NOTE:
- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Color Indication of Appearance Parts
  Example:
  KNOB, BALANCE(WHITE)...(RED)
  ↑ ↑
  Parts color Cabinet's color

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- hardware (#mark) list is given in the last of this parts list.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

IT: Italian

4-1. CABINET SECTION



Ref. No.	Part No.	Description	Remark
* 1	4-942-291-01	CASE (AEP, UK)	
* 1	4-942-291-31	CASE (IT)	
2	4-929-973-01	SCREW (CASE, 3 POINT)	
* 3	3-703-244-00	BUSHING (2104), CORD	
* 4	4-948-282-11	PANEL, BACK (AEP)	
* 4	4-948-282-21	PANEL, BACK (UK)	
* 4	4-948-282-31	PANEL, BACK (IT)	
5	X-4941-228-1	FOOT ASSY	
6	4-812-134-11	RIVET NYLON, 3.5	
* 7	4-943-687-21	HOLDER, PC BOARD	
* 8	1-641-708-11	POWER BOARD	
* 9	A-4345-905-A	POWER AMP BOARD, COMPLETE (AEP, UK)	
* 9	A-4347-082-A	POWER AMPLIFIER BOARD, COMPLETE (IT)	
* 10	A-4345-902-A	MAIN BOARD, COMPLETE (AEP, UK)	
* 10	A-4347-079-A	MAIN BOARD, COMPLETE (IT)	
11	1-590-459-11	WIRE, FLAT TYPE (11 CORE)	
12	1-590-578-11	WIRE, FLAT TYPE (19 CORE)	
13	3-363-099-01	SCREW (CASE +3X8 TP2)	
* 14	4-949-235-01	HOOK	
⚠	CNP13011-575-651-61	CORD, POWER (AEP, IT)	
⚠	CNP13011-575-652-21	CORD, POWER (UK)	
⚠	F1301 1-532-237-00	FUSE, TIME LAG (3.15A)	
⚠	F1302 1-532-237-00	FUSE, TIME LAG (3.15A)	
⚠	F1303 1-532-203-00	FUSE (2.0A)	
⚠	F1304 1-532-203-00	FUSE (2.0A)	
⚠	T1301 1-450-308-11	TRANSFORMER, POWER (AEP, IT)	
⚠	T1301 1-450-743-11	TRANSFORMER, POWER (UK)	

4-2. FRONT PANEL SECTION



Ref. No.	Part No.	Description	Remark
51	A-4325-346-A	LID (A) ASSY, CASSETTE (AEP, UK)	
51	A-4325-422-A	LID (A) ASSY, CASSETTE (IT)	
52	A-4325-347-A	LID (B) ASSY, CASSETTE (AEP, UK)	
52	A-4325-423-A	LID (B) ASSY, CASSETTE (IT)	
53	A-4323-382-A	KNOB (VO) ASSY	
54	4-950-672-01	NUT (M9), VOL	
55	4-948-270-01	KNOB (DSB)	
56	4-948-236-01	CUSHION (107)	
57	A-4325-348-A	PANEL ASSY, FRONT (AEP, UK)	
57	A-4325-424-A	PANEL ASSY, FRONT (IT)	
58	4-930-783-11	BUTTON (PO)	
⚠ 59	1-690-708-11	CORD (WITH CONNECTOR)	
* 60	1-641-707-11	H.P. BOARD	
* 61	1-641-709-11	SW BOARD	
62	4-948-257-01	BUTTON (DDT)	
* 63	1-641-706-11	VOL BOARD	
* 64	A-4345-906-A	PANEL BOARD, COMPLETE (AEP, UK)	
* 64	A-4347-076-A	PANEL BOARD, COMPLETE (IT)	
65	4-948-258-01	BUTTON (MD-A)	
66	4-948-259-01	BUTTON (MD-B)	
* 67	4-924-098-31	HOLDER, PC BOARD	
* 68	A-4345-901-A	TC MAIN BOARD, COMPLETE	
69	4-928-635-01	SCREW, +BV (2.6X8) TAPPING	
70	4-928-635-21	SCREW, +BV (2.6X10) TAPPING	
71	3-701-748-00	CLAMP	
⚠ S1301	1-572-267-61	SWITCH, PUSH (AC POWER) (1 KEY)	

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

4-5. MECHANISM DECK SECTION-3
(TCM-180VW-H7)



Ref. No.	Part No.	Description	Remark
101	3-358-287-01	SPRING (LOADING A), TORSION	
102	3-358-229-01	SPRING (LOADING), TORSION	
103	3-358-209-01	SPRING (CASSETTE HOLDER), LEAF	
104	3-358-266-02	HOLDER, CASSETTE	
105	3-371-917-01	SHAFT (BUTTON SHAFT 4)	
106	3-369-335-01	LEVER (BUTTON BASE F)	
* 107	3-358-216-01	COLLAR (DECK A)	
* 108	1-640-702-12	LEAF SW (A) BOARD	
* 109	3-358-289-01	SPACER (VIBRATION PROOF MAT)	
110	3-358-203-01	LEVER (TRIGGER)	
111	3-358-202-01	SLIDER (TRIGGER)	
* 112	3-363-930-01	BRACKET (JOINT BASE)	

Ref. No.	Part No.	Description	Remark
113	3-358-230-01	BELT (A1)	
114	3-364-777-01	BELT (WH)	
* 115	1-640-703-12	LEAF SW (B) BOARD	
116	4-928-635-01	SCREW +BV (2.6X8) TAPPING	
* CN415	1-568-942-11	PIN, CONNECTOR 4P	
* CN416	1-568-943-11	PIN, CONNECTOR 5P	
M1	X-3362-377-1	MOTOR (WH) ASSY	
S1	1-571-736-11	SWITCH, LEAF (MOTOR)	
S2	1-571-736-11	SWITCH, LEAF (FWD)	
S3	1-571-736-11	SWITCH, LEAF (REC)	
S4	1-571-736-11	SWITCH, LEAF (MOTOR)	
S5	1-571-736-11	SWITCH, LEAF (FWD)	

4-4. MECHANISM DECK SECTION-2
(TCM-180VW-H7)



Ref. No.	Part No.	Description	Remark
151	3-358-232-01	SPRING (S-P F-R), TORSION	
152	3-358-258-01	SLIDER (REW)	
153	3-358-257-01	SLIDER (FF)	
154	3-358-256-01	SLIDER (STOP/EJECT)	
155	3-358-260-01	SLIDER (PAUSE)	
* 156	3-358-226-01	LEVER (PAUSE LEVER)	
* 157	3-358-261-02	SLIDER (HOLDER LOCK)	
158	3-701-437-01	WASHER	
159	X-3358-205-1	FLYWHEEL (A) ASSY (DECK A)	
159	X-3358-206-1	FLYWHEEL (B) ASSY (DECK B)	
* 160	X-3358-208-1	BRACKET (B) ASSY	

Ref. No.	Part No.	Description	Remark
* 161	3-358-249-01	SLIDER (LOCK PLATE)	
162	3-358-230-01	BELT (A1)	
163	X-3358-202-1	LEVER (FR ARM) ASSY	
164	3-358-259-01	SLIDER (REC) (DECK B)	
* 165	3-358-204-01	LEVER (REC SAFETY) (DECK B)	
166	3-358-286-01	LEVER (MOTOR LEVER)	
167	3-358-214-01	SPRING (LOCK), TORSION (DECK A)	
167	3-358-233-01	SPRING (REC-LOCK), TORSION (DECK B)	
168	3-319-224-41	DAMPER, SMALL	
* 169	3-358-289-01	SPACER (VIBRATION PROOF MAT)	

4-5. MECHANISM DECK SECTION-3
(TCM-180VW-H7)



Ref. No.	Part No.	Description	Remark
201	X-3358-204-1	LEVER (PINCH LEVER) ASSY	
202	3-578-143-11	PINCH ROLLER	
* 203	3-358-215-01	BUSHING (WIRE KIT RETAINER)	
204	3-358-265-01	SLIDER (HEAD PC BOARD A)	
205	3-358-217-01	SPRING, TENSION	
* 206	3-363-931-01	GUIDE, TAPE (DECK A)	
207	3-358-288-11	SCREW (T), AZIMUTH	
208	3-358-234-01	SPRING (AZIMUTH), COMPRESSION	
209	3-358-288-01	SCREW (T), AZIMUTH	
210	3-358-248-01	GEAR (SUPPLY REEL)	
211	X-3358-203-1	TABLE (T) ASSY, REEL	
212	3-358-208-01	SPRING (SUPPLY), COMPRESSION	
* 213	3-358-251-01	LEVER (TENSION DETECTION ARM)	

Ref. No.	Part No.	Description	Remark
214	3-358-228-01	SPRING, TORSION	
* 215	3-358-255-01	LEVER (GB LEVER)	
* 216	3-358-224-01	GEAR (FF GEAR)	
217	3-358-207-01	SPRING (FF GEAR), COMPRESSION	
218	3-358-227-01	SPRING, LEAF	
* 219	3-358-284-01	GEAR (TU GEAR)	
* 220	3-358-252-01	LEVER (TU ARM)	
* 221	3-358-253-01	LEVER (SHUT-OFF LEVER)	
222	3-358-243-01	SPRING (TU-SHUT), TORSION	
HE1	1-543-673-11	HEAD, MAGNETIC (ERASE) (DECK B)	
HP1	1-543-319-11	HEAD, MAGNETIC (PB) (DECK A)	
HRP1	1-543-319-11	HEAD, MAGNETIC (REC/PB) (DECK B)	

SECTION 5
ELECTRICAL PARTS LIST

LEAF SW(A) LEAF SW(B) MAIN

NOTE:
- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some differences from the original one.
- RESISTORS
  All resistors are in ohms
  METAL:Metal-film resistor
  METAL OXIDE:Metal Oxide-film resistor
  F:nonflammable
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
  In each case, u:μ , for example:
  uA...: μA..., uPA...: μPA...,
  uPB...: μPB..., uPC...: μPC...,
  uPD...: μPD...
- CAPACITORS
  uF: μF
- COILS
  uH: μH

When indication parts by reference number, please include the board name.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

IT:Italian

Ref.No.	Part No.	Description			Remark
*	1-640-702-12	LEAF SW (A) BOARD			
		**********			
		< CAPACITOR >			
C544	1-164-159-11	CERAMIC	0.1uF		50V
		< CONNECTOR >			
* CN415	1-568-942-11	PIN, CONNECTOR 4P			
		< SWITCH >			
S4	1-571-736-11	SWITCH, LEAF (MOTOR)			
S5	1-571-736-11	SWITCH, LEAF (FWD)			
**********					
*	1-640-703-12	LEAF SW (B) BOARD			
		**********			
		< CAPACITOR >			
C545	1-164-159-11	CERAMIC	0.1uF		50V
		< CONNECTOR >			
* CN416	1-568-943-11	PIN, CONNECTOR 5P			
		< SWITCH >			
S1	1-571-736-11	SWITCH, LEAF (MOTOR)			
S2	1-571-736-11	SWITCH, LEAF (FWD)			
S3	1-571-736-11	SWITCH, LEAF (REC)			
**********					

Ref.No.	Part No.	Description			Remark
*	A-4345-902-A	MAIN BOARD, COMPLETE (AEP, UK)			
*	A-4347-079-A	MAIN BOARD, COMPLETE (IT)			
		**********			
*	4-942-204-01	PLATE, GROUND			
	7-685-646-79	SCREW +BVTP 3X8 TYPE2 N-S			
		< CAPACITOR >			
C301	1-161-379-00	CERAMIC	0.01uF	20%	25V (IT)
C302	1-124-477-11	ELECT	47uF	20%	25V
C303	1-161-379-00	CERAMIC	0.01uF	20%	25V
C305	1-161-379-00	CERAMIC	0.01uF	20%	25V (IT)
C306	1-161-379-00	CERAMIC	0.01uF	20%	25V (IT)
C307	1-161-379-00	CERAMIC	0.01uF	20%	25V
C308	1-161-379-00	CERAMIC	0.01uF	20%	25V
C309	1-161-379-00	CERAMIC	0.01uF	20%	25V
C310	1-124-477-11	ELECT	47uF	20%	25V
C311	1-161-379-00	CERAMIC	0.01uF	20%	25V
C312	1-101-006-00	CERAMIC	0.047uF		50V
C313	1-123-382-00	ELECT	3.3uF	20%	100V
C314	1-161-379-00	CERAMIC	0.01uF	20%	25V
C315	1-161-329-00	CERAMIC	0.0068uF	30%	16V
C316	1-162-282-31	CERAMIC	100PF	10%	50V
C317	1-162-292-31	CERAMIC	680PF	10%	50V (IT)
C318	1-124-903-11	ELECT	1uF	20%	50V
C320	1-124-903-11	ELECT	1uF	20%	50V
C321	1-124-902-00	ELECT	0.47uF	20%	50V
C322	1-124-463-00	ELECT	0.1uF	20%	50V
C323	1-161-329-00	CERAMIC	0.0068uF	30%	16V
C324	1-161-329-00	CERAMIC	0.0068uF	30%	16V
C325	1-124-477-11	ELECT	47uF	20%	25V
C326	1-124-907-11	ELECT	10uF	20%	50V
C327	1-161-379-00	CERAMIC	0.01uF	20%	25V

MAIN

Ref. No.	Part No.	Description			Remark
C328	1-124-463-00	ELECT	0.1uF	20%	50V
C329	1-124-927-11	ELECT	4.7uF	20%	100V
C330	1-161-379-00	CERAMIC	0.01uF	20%	25V
C331	1-126-176-11	ELECT	220uF	20%	10V
C332	1-161-379-00	CERAMIC	0.01uF	20%	25V
C335	1-161-379-00	CERAMIC	0.01uF	20%	25V
C336	1-161-379-00	CERAMIC	0.01uF	20%	25V
C339	1-162-210-31	CERAMIC	30PF	5%	50V
C341	1-123-382-00	ELECT	3.3uF	20%	100V
C342	1-123-382-00	ELECT	3.3uF	20%	100V
C343	1-123-382-00	ELECT	3.3uF	20%	100V
C344	1-123-382-00	ELECT	3.3uF	20%	100V
C345	1-161-375-00	CERAMIC	0.0022uF	20%	50V
C346	1-161-375-00	CERAMIC	0.0022uF	20%	50V
C351	1-161-494-00	CERAMIC	0.022uF		25V
C352	1-102-120-00	CERAMIC	0.0018uF	10%	50V
C353	1-161-374-11	CERAMIC	0.0015uF	20%	50V
C354	1-161-494-00	CERAMIC	0.022uF		25V
C361	1-164-098-11	CERAMIC	0.047uF		12V
C362	1-161-494-00	CERAMIC	0.022uF		25V
C363	1-164-159-11	CERAMIC	0.1uF		50V
C364	1-161-494-00	CERAMIC	0.022uF		25V
C371	1-162-196-31	CERAMIC	5.6PF	10%	50V
C501	1-102-961-00	CERAMIC	27PF	5%	50V
C502	1-102-961-00	CERAMIC	27PF	5%	50V
C503	1-124-477-11	ELECT	47uF	20%	25V
C504	1-161-379-00	CERAMIC	0.01uF	20%	25V
C505	1-161-379-00	CERAMIC	0.01uF	20%	25V
C506	1-161-379-00	CERAMIC	0.01uF	20%	25V
C507	1-161-379-00	CERAMIC	0.01uF	20%	25V
C521	1-124-925-11	ELECT	2.2uF	20%	100V
C522	1-124-463-00	ELECT	0.1uF	20%	50V
C523	1-161-379-00	CERAMIC	0.01uF	20%	25V
C524	1-161-379-00	CERAMIC	0.01uF	20%	25V
C525	1-124-477-11	ELECT	47uF	20%	25V
C530	1-161-379-00	CERAMIC	0.01uF	20%	25V (IT)
C531	1-136-173-00	FILM	0.47uF	5%	50V
C532	1-161-494-00	CERAMIC	0.022uF		25V
C533	1-124-463-00	ELECT	0.1uF	20%	50V
C1001	1-124-925-11	ELECT	2.2uF	20%	100V
C1002	1-162-282-31	CERAMIC	100PF	10%	50V
C1003	1-162-282-31	CERAMIC	100PF	10%	50V
C1004	1-124-477-11	ELECT	47uF	20%	25V
C1005	1-161-377-00	CERAMIC	0.0047uF	20%	16V
C1006	1-161-374-11	CERAMIC	0.0015uF	20%	50V
C1007	1-124-464-11	ELECT	0.22uF	20%	50V
C1008	1-124-477-11	ELECT	47uF	20%	25V
C1009	1-124-925-11	ELECT	2.2uF	20%	100V
C1010	1-124-477-11	ELECT	47uF	20%	25V

Ref. No.	Part No.	Description			Remark
C1012	1-124-925-11	ELECT	2.2uF	20%	100V
C1013	1-162-290-31	CERAMIC	470PF	10%	50V
C1014	1-161-494-00	CERAMIC	0.022uF		25V
C1025	1-162-286-31	CERAMIC	220PF	10%	50V
C1026	1-162-286-31	CERAMIC	220PF	10%	50V
C1051	1-124-925-11	ELECT	2.2uF	20%	100V
C1052	1-162-282-31	CERAMIC	100PF	10%	50V
C1053	1-162-282-31	CERAMIC	100PF	10%	50V
C1054	1-124-477-11	ELECT	47uF	20%	25V
C1055	1-161-377-00	CERAMIC	0.0047uF	20%	16V
C1056	1-161-374-11	CERAMIC	0.0015uF	20%	50V
C1057	1-124-464-11	ELECT	0.22uF	20%	50V
C1058	1-124-477-11	ELECT	47uF	20%	25V
C1059	1-124-925-11	ELECT	2.2uF	20%	100V
C1060	1-124-477-11	ELECT	47uF	20%	25V
C1062	1-124-925-11	ELECT	2.2uF	20%	100V
C1063	1-162-290-31	CERAMIC	470PF	10%	50V
C1064	1-161-494-00	CERAMIC	0.022uF		25V
C1075	1-162-286-31	CERAMIC	220PF	10%	50V
C1076	1-162-286-31	CERAMIC	220PF	10%	50V
C1212	1-126-233-11	ELECT	22uF	20%	50V
C1213	1-126-233-11	ELECT	22uF	20%	50V
C1221	1-126-101-11	ELECT	100uF	20%	16V
C1222	1-126-176-11	ELECT	220uF	20%	10V
C1223	1-126-176-11	ELECT	220uF	20%	10V
C1239	1-161-494-00	CERAMIC	0.022uF		25V (IT)
C1245	1-101-006-00	CERAMIC	0.047uF		50V (IT)
C1246	1-101-006-00	CERAMIC	0.047uF		50V (IT)
C1247	1-101-006-00	CERAMIC	0.047uF		50V (IT)
C1248	1-101-006-00	CERAMIC	0.047uF		50V (IT)
C1249	1-161-494-00	CERAMIC	0.022uF		25V (IT)
C1250	1-161-494-00	CERAMIC	0.022uF		25V (IT)
C1262	1-126-233-11	ELECT	22uF	20%	50V
C1263	1-126-233-11	ELECT	22uF	20%	50V
C1294	1-161-494-00	CERAMIC	0.022uF		25V (IT)
C1302	1-102-394-11	CERAMIC	0.01uF		250V
C1304	1-126-413-11	ELECT	3300uF	20%	35V
C1305	1-126-413-11	ELECT	3300uF	20%	35V
C1306	1-124-477-11	ELECT	47uF	20%	25V
C1308	1-126-101-11	ELECT	100uF	20%	16V
C1309	1-126-101-11	ELECT	100uF	20%	16V
C1312	1-124-563-11	ELECT	2200uF	20%	25V
C1313	1-124-563-11	ELECT	2200uF	20%	25V
C1319	1-124-463-00	ELECT	0.1uF	20%	50V
C1320	1-124-907-11	ELECT	10uF	20%	50V
C1321	1-161-379-00	CERAMIC	0.01uF	20%	25V
C1322	1-161-379-00	CERAMIC	0.01uF	20%	25V
C1324	1-124-907-11	ELECT	10uF	20%	50V

Ref. No.	Part No.	Description			Remark
C1326	1-124-907-11	ELECT	10uF	20%	50V
C1330	1-126-101-11	ELECT	100uF	20%	16V
C1331	1-102-394-11	CERAMIC	0.01uF		250V
C1335	1-124-907-11	ELECT	10uF	20%	50V
C1336	1-126-101-11	ELECT	100uF	20%	16V
C1341	1-124-907-11	ELECT	10uF	20%	50V
C1346	1-124-925-11	ELECT	2.2uF	20%	100V
C1351	1-124-122-11	ELECT	100uF	20%	50V
C1352	1-126-105-11	ELECT	1000uF	20%	35V
C1353	1-136-165-00	FILM	0.1uF	5%	50V
C1354	1-136-165-00	FILM	0.1uF	5%	50V
C1361	1-124-122-11	ELECT	100uF	20%	50V
		< FILTER >			
CF301	1-567-389-11	FILTER, CERAMIC (IT)			
CF301	1-577-070-81	FILTER, CERAMIC (AEP, UK)			
CF303	1-567-389-11	FILTER, CERAMIC (IT)			
CF303	1-577-070-81	FILTER, CERAMIC (AEP, UK)			
CF304	1-577-075-11	OSCILLATOR, CERAMIC			
		< CONNECTOR >			
* CN501	1-568-830-11	SOCKET, CONNECTOR 11P			
* CN1001	1-580-912-11	JACK, PIN 4P			
* CN1002	1-580-691-11	JACK, PIN 2P			
* CN1201	1-537-327-11	TERMINAL BOARD			
* CN1202	1-569-130-11	JACK, PIN 2P			
* CN1203	1-564-506-11	PLUG, CONNECTOR 3P			
* CN1204	1-564-510-11	PLUG, CONNECTOR 7P			
* CN1205	1-568-934-11	PIN, CONNECTOR 7P			
CN1206	1-568-802-11	SOCKET, CONNECTOR 19P			
* CN1211	1-564-506-11	PLUG, CONNECTOR 3P			
* CN1212	1-564-508-11	PLUG, CONNECTOR 5P			
* CN1301	1-566-210-11	PIN, CONNECTOR 3P			
		< DIODE >			
D351	8-719-987-63	DIODE	1N4148M		
D1202	8-719-987-63	DIODE	1N4148M		
D1203	8-719-987-63	DIODE	1N4148M		
D1204	8-719-987-63	DIODE	1N4148M		
D1302	8-719-312-09	DIODE	RBA-402		
D1303	8-719-200-82	DIODE	11ES2		
D1304	8-719-200-82	DIODE	11ES2		
D1305	8-719-200-82	DIODE	11ES2		
D1306	8-719-200-82	DIODE	11ES2		
D1318	8-719-200-82	DIODE	11ES2		
D1319	8-719-200-82	DIODE	11ES2		
D1321	8-719-987-63	DIODE	1N4148M		
D1323	8-719-987-63	DIODE	1N4148M		
D1324	8-719-987-63	DIODE	1N4148M		

Ref. No.	Part No.	Description		Remark
D1341	8-719-001-76	DIODE	UZL-12M3	
D1368	8-719-200-82	DIODE	11ES2	
D1369	8-719-200-82	DIODE	11ES2	
		< FRONT END >		
FE301	1-465-006-11	FRONT END (FM) (2 GANG)		(AEP, UK)
FE301	1-463-857-21	FRONT END (FM)		(IT)
FE351	1-236-463-11	ENCAPSULATED COMPONENT		
FE352	1-239-261-11	ENCAPSULATED COMPONENT		
		< IC >		
IC301	8-759-821-45	IC	LA1851N	
IC501	8-759-820-91	IC	LC7218	
IC1001	8-759-634-51	IC	M5218AP	
IC1002	8-759-000-48	IC	MC14052BCP	
IC1003	8-759-634-51	IC	M5218AP	
IC1004	8-759-000-49	IC	MC14066BCP	
IC1202	8-759-111-68	IC	uPC1237HA	
IC1303	8-759-604-86	IC	M5F7807L	
IC1304	8-759-604-90	IC	M5F7907L	
IC1305	8-759-820-13	IC	L78MR06	
IC1306	8-759-231-58	IC	TA7812S	
		< TRANSFORMER >		
IFT301	1-404-713-11	TRANSFORMER, IF		
		< COIL >		
L301	1-407-500-00	INDUCTOR	4.7mH	
L351	1-410-525-11	INDUCTOR	220uH	
L1301	1-408-117-00	INDUCTOR	10uH (IT)	
L1302	1-408-117-00	INDUCTOR	10uH (IT)	
		< FILTER >		
LPF301	1-235-164-00	FILTER, LOW PASS		
LPF302	1-235-164-00	FILTER, LOW PASS		
		< TRANSISTOR >		
Q301	8-729-230-XX	TRANSISTOR	2SC2669-OY (IT)	
Q302	8-729-230-XX	TRANSISTOR	2SC2669-OY (IT)	
Q303	8-729-230-XX	TRANSISTOR	2SC2669-OY	
Q304	8-729-230-XX	TRANSISTOR	2SC2669-OY	
Q305	8-729-900-80	TRANSISTOR	DTC114ES	
Q306	8-729-900-61	TRANSISTOR	DTA114ES	
Q307	8-729-900-80	TRANSISTOR	DTC114ES	
Q308	8-729-119-78	TRANSISTOR	2SC2785-HFE	
Q309	8-729-119-78	TRANSISTOR	2SC2785-HFE	
Q351	8-729-900-80	TRANSISTOR	DTC114ES	

MAIN

Ref. No.	Part No.	Description		Remark
Q352	8-729-119-78	TRANSISTOR	2SC2785-HFE	
Q353	8-729-119-76	TRANSISTOR	2SA1175-HFE	
Q354	8-729-900-80	TRANSISTOR	DTC114ES	
Q355	8-729-900-80	TRANSISTOR	DTC114ES	
Q356	8-729-900-80	TRANSISTOR	DTC114ES	
Q501	8-729-900-80	TRANSISTOR	DTC114ES	
Q502	8-729-900-61	TRANSISTOR	DTA114ES	
Q521	8-729-202-67	TRANSISTOR	2SK246-GR3	
Q522	8-729-201-84	TRANSISTOR	2SC3112-B	
Q531	8-729-202-67	TRANSISTOR	2SK246-GR3	
Q532	8-729-201-84	TRANSISTOR	2SC3112-B	
Q1001	8-729-119-76	TRANSISTOR	2SA1175-HFE	
Q1002	8-729-900-36	TRANSISTOR	DTC124ES	
Q1204	8-729-900-63	TRANSISTOR	DTA124ES	
Q1302	8-729-209-15	TRANSISTOR	2SD2012	

< RESISTOR >

R301	1-249-401-11	CARBON	47	5%	1/4W
R302	1-249-405-11	CARBON	100	5%	1/4W (IT)
R302	1-249-413-11	CARBON	470	5%	1/4W (AEP, UK)
R303	1-249-411-11	CARBON	330	5%	1/4W (IT)
R304	1-249-432-11	CARBON	18K	5%	1/4W (IT)
R305	1-249-411-11	CARBON	330	5%	1/4W (IT)
R306	1-249-434-11	CARBON	27K	5%	1/4W (IT)
R307	1-249-414-11	CARBON	560	5%	1/4W (IT)
R308	1-249-411-11	CARBON	330	5%	1/4W
R309	1-249-432-11	CARBON	18K	5%	1/4W
R310	1-249-411-11	CARBON	330	5%	1/4W
R311	1-249-434-11	CARBON	27K	5%	1/4W
R312	1-249-414-11	CARBON	560	5%	1/4W
R313	1-249-405-11	CARBON	100	5%	1/4W
R314	1-249-437-11	CARBON	47K	5%	1/4W (IT)
R315	1-249-404-00	CARBON	82	5%	1/4W
R316	1-249-429-11	CARBON	10K	5%	1/4W
R317	1-249-417-11	CARBON	1K	5%	1/4W
R318	1-249-435-11	CARBON	33K	5%	1/4W
R319	1-249-428-11	CARBON	8.2K	5%	1/4W
R320	1-249-432-11	CARBON	18K	5%	1/4W
R321	1-249-423-11	CARBON	3.3K	5%	1/4W
R322	1-249-429-11	CARBON	10K	5%	1/4W
R323	1-249-418-11	CARBON	1.2K	5%	1/4W (AEP, UK)
R323	1-249-417-11	CARBON	1K	5%	1/4W (IT)
R324	1-249-429-11	CARBON	10K	5%	1/4W
R325	1-249-429-11	CARBON	10K	5%	1/4W
R326	1-249-409-11	CARBON	220	5%	1/4W
R327	1-249-437-11	CARBON	47K	5%	1/4W
R328	1-249-437-11	CARBON	47K	5%	1/4W
R331	1-247-891-00	CARBON	330K	5%	1/4W
R332	1-247-891-00	CARBON	330K	5%	1/4W
R333	1-249-421-11	CARBON	2.2K	5%	1/4W
R334	1-249-421-11	CARBON	2.2K	5%	1/4W
R335	1-249-420-11	CARBON	1.8K	5%	1/4W
R336	1-249-420-11	CARBON	1.8K	5%	1/4W
R337	1-249-426-11	CARBON	5.6K	5%	1/4W
R338	1-249-426-11	CARBON	5.6K	5%	1/4W
R351	1-249-433-11	CARBON	22K	5%	1/4W
R352	1-249-437-11	CARBON	47K	5%	1/4W
R353	1-247-903-00	CARBON	1M	5%	1/4W
R354	1-249-441-11	CARBON	100K	5%	1/4W
R355	1-249-433-11	CARBON	22K	5%	1/4W
R356	1-249-421-11	CARBON	2.2K	5%	1/4W
R361	1-249-437-11	CARBON	47K	5%	1/4W
R362	1-249-437-11	CARBON	47K	5%	1/4W
R363	1-249-425-11	CARBON	4.7K	5%	1/4W
R364	1-249-425-11	CARBON	4.7K	5%	1/4W
R365	1-249-429-11	CARBON	10K	5%	1/4W
R366	1-249-413-11	CARBON	470	5%	1/4W
R367	1-249-434-11	CARBON	27K	5%	1/4W
R368	1-249-433-11	CARBON	22K	5%	1/4W
R501	1-249-417-11	CARBON	1K	5%	1/4W
R502	1-249-417-11	CARBON	1K	5%	1/4W
R503	1-249-417-11	CARBON	1K	5%	1/4W
R504	1-249-417-11	CARBON	1K	5%	1/4W
R505	1-249-429-11	CARBON	10K	5%	1/4W
R506	1-249-417-11	CARBON	1K	5%	1/4W
R510	1-249-401-11	CARBON	47	5%	1/4W
R511	1-249-429-11	CARBON	10K	5%	1/4W
R512	1-249-425-11	CARBON	4.7K	5%	1/4W
R513	1-249-417-11	CARBON	1K	5%	1/4W
R514	1-249-429-11	CARBON	10K	5%	1/4W
R515	1-249-417-11	CARBON	1K	5%	1/4W
R521	1-249-423-11	CARBON	3.3K	5%	1/4W
R522	1-249-425-11	CARBON	4.7K	5%	1/4W
R523	1-249-414-11	CARBON	560	5%	1/4W
R524	1-249-417-11	CARBON	1K	5%	1/4W
R525	1-249-410-11	CARBON	270	5%	1/4W
R526	1-249-421-11	CARBON	2.2K	5%	1/4W
R527	1-249-425-11	CARBON	4.7K	5%	1/4W
R528	1-249-425-11	CARBON	4.7K	5%	1/4W
R529	1-249-405-11	CARBON	100	5%	1/4W
R530	1-249-405-11	CARBON	100	5%	1/4W
R531	1-249-423-11	CARBON	3.3K	5%	1/4W
R532	1-249-433-11	CARBON	22K	5%	1/4W
R533	1-249-414-11	CARBON	560	5%	1/4W
R534	1-249-417-11	CARBON	1K	5%	1/4W
R535	1-249-410-11	CARBON	270	5%	1/4W

MAIN PANEL

Ref. No.	Part No.	Description				Remark
R536	1-249-421-11	CARBON	2.2K	5%	1/4W	
R537	1-249-425-11	CARBON	4.7K	5%	1/4W	
R538	1-249-405-11	CARBON	100	5%	1/4W	
R1001	1-249-417-11	CARBON	1K	5%	1/4W	
R1002	1-249-441-11	CARBON	100K	5%	1/4W	
R1003	1-249-416-11	CARBON	820	5%	1/4W	
R1004	1-247-897-11	CARBON	560K	5%	1/4W	
R1005	1-249-437-11	CARBON	47K	5%	1/4W	
R1006	1-249-409-11	CARBON	220	5%	1/4W	
R1007	1-249-441-11	CARBON	100K	5%	1/4W	
R1008	1-249-409-11	CARBON	220	5%	1/4W	
R1010	1-249-422-11	CARBON	2.7K	5%	1/4W	
R1011	1-249-428-11	CARBON	8.2K	5%	1/4W	
R1012	1-249-417-11	CARBON	1K	5%	1/4W	
R1013	1-249-441-11	CARBON	100K	5%	1/4W	
R1014	1-249-437-11	CARBON	47K	5%	1/4W	
R1015	1-249-437-11	CARBON	47K	5%	1/4W	
R1016	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1017	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1018	1-249-433-11	CARBON	22K	5%	1/4W	
R1019	1-249-433-11	CARBON	22K	5%	1/4W	
R1021	1-249-434-11	CARBON	27K	5%	1/4W	
R1023	1-249-434-11	CARBON	27K	5%	1/4W	
R1024	1-249-417-11	CARBON	1K	5%	1/4W	
R1026	1-249-433-11	CARBON	22K	5%	1/4W	
R1029	1-249-433-11	CARBON	22K	5%	1/4W	
R1037	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1051	1-249-417-11	CARBON	1K	5%	1/4W	
R1052	1-249-441-11	CARBON	100K	5%	1/4W	
R1053	1-249-416-11	CARBON	820	5%	1/4W	
R1054	1-247-897-11	CARBON	560K	5%	1/4W	
R1055	1-249-437-11	CARBON	47K	5%	1/4W	
R1056	1-249-409-11	CARBON	220	5%	1/4W	
R1057	1-249-441-11	CARBON	100K	5%	1/4W	
R1058	1-249-409-11	CARBON	220	5%	1/4W	
R1060	1-249-422-11	CARBON	2.7K	5%	1/4W	
R1061	1-249-428-11	CARBON	8.2K	5%	1/4W	
R1062	1-249-417-11	CARBON	1K	5%	1/4W	
R1063	1-249-441-11	CARBON	100K	5%	1/4W	
R1071	1-249-434-11	CARBON	27K	5%	1/4W	
R1073	1-249-434-11	CARBON	27K	5%	1/4W	
R1074	1-249-417-11	CARBON	1K	5%	1/4W	
R1095	1-249-433-11	CARBON	22K	5%	1/4W	
R1222	1-249-415-11	CARBON	680	5%	1/4W	
R1223	1-249-415-11	CARBON	680	5%	1/4W	
R1226	1-215-887-00	METAL OXIDE	150	5%	2W	F
R1233	1-249-432-11	CARBON	18K	5%	1/4W	
R1234	1-249-432-11	CARBON	18K	5%	1/4W	
R1235	1-249-435-11	CARBON	33K	5%	1/4W	

Ref. No.	Part No.	Description				Remark
R1236	1-249-441-11	CARBON	100K	5%	1/4W	
R1237	1-249-429-11	CARBON	10K	5%	1/4W	
R1240	1-249-438-11	CARBON	56K	5%	1/4W	
R1272	1-249-415-11	CARBON	680	5%	1/4W	
R1273	1-249-415-11	CARBON	680	5%	1/4W	
R1290	1-249-437-11	CARBON	47K	5%	1/4W	
R1301	1-249-429-11	CARBON	10K	5%	1/4W	
R1302	1-249-429-11	CARBON	10K	5%	1/4W	
R1321	1-249-417-11	CARBON	1K	5%	1/4W	
R1322	1-249-429-11	CARBON	10K	5%	1/4W	
R1241	1-249-385-11	CARBON	2.2	5%	1/6W	(IT)
R1242	1-249-385-11	CARBON	2.2	5%	1/6W	(IT)
R1243	1-249-385-11	CARBON	2.2	5%	1/6W	(IT)
R1244	1-249-385-11	CARBON	2.2	5%	1/6W	(IT)
R1345	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1346	1-249-425-11	CARBON	4.7K	5%	1/4W	

< VARIABLE RESISTOR >

RV301	1-238-601-11	RES, ADJ, CARBON 22K
RV302	1-238-601-11	RES, ADJ, CARBON 22K

< RELAY >

RY1201	1-515-533-11	RELAY

< TRANSFORMER >

T301	1-404-807-11	TRANSFORMER, DISCRIMINATOR
T302	1-235-126-00	ENCAPSULATED COMPONENT (IT)

< TERMINAL >

* TM301	1-537-288-11	TERMINAL BOARD (PAL)

< TEST PIN >

* TP1	1-560-060-00	PIN, CONNECTOR 2P

< CRYSTAL >

XT501	1-577-126-11	VIBRATOR, CRYSTAL
XT501	1-579-383-11	VIBRATOR, CRYSTAL

****

*	A-4345-906-A	PANEL BOARD, COMPLETE (AEP, UK)
*	A-4347-082-A	PANEL BOARD, COMPLETE (IT)

****

*	1-564-321-00	PIN, CONNECTOR 2P
	4-352-844-01	PIN, LEAD, COATING
*	4-930-781-11	HOLDER (VO), LED
*	4-942-301-01	HOLDER, FL TUBE
*	4-948-247-01	HOLDER (FU), LED
*	4-949-935-01	CUSHION (FL)

PANEL

Ref. No.	Part No.	Description			Remark
		< CAPACITOR >			
C603	1-136-169-00	FILM	0.22uF	5%	50V
C604	1-164-159-11	CERAMIC	0.1uF		50V
C605	1-125-486-11	DOUBLE LAYERS	0.22F		5.5V
C606	1-164-159-11	CERAMIC	0.1uF		50V
C607	1-124-907-11	ELECT	10uF	20%	50V
C608	1-161-379-00	CERAMIC	0.01uF	20%	25V
C609	1-161-379-00	CERAMIC	0.01uF	20%	25V
C650	1-124-907-11	ELECT	10uF	20%	50V
C1101	1-124-257-00	ELECT	2.2uF	20%	50V
C1102	1-124-589-11	ELECT	47uF	20%	16V
C1103	1-162-282-31	CERAMIC	100PF	10%	50V
C1104	1-124-257-00	ELECT	2.2uF	20%	50V
C1105	1-124-464-11	ELECT	0.22uF	20%	50V
C1106	1-136-161-00	FILM	0.047uF	5%	50V
C1107	1-136-155-00	FILM	0.015uF	5%	50V
C1108	1-136-155-00	FILM	0.015uF	5%	50V
C1109	1-130-480-00	MYLAR	0.0056uF	5%	50V
C1110	1-161-327-00	CERAMIC	0.0033uF	20%	16V
C1111	1-136-155-00	FILM	0.015uF	5%	50V
C1112	1-136-157-00	FILM	0.022uF	5%	50V
C1113	1-136-153-00	FILM	0.01uF	5%	50V
C1114	1-161-377-00	CERAMIC	0.0047uF	20%	16V
C1115	1-124-257-00	ELECT	2.2uF	20%	50V
C1121	1-161-379-00	CERAMIC	0.01uF	20%	25V
C1123	1-162-286-31	CERAMIC	220PF	10%	50V
C1131	1-162-215-31	CERAMIC	47PF	5%	50V
C1132	1-162-215-31	CERAMIC	47PF	5%	50V
C1151	1-124-257-00	ELECT	2.2uF	20%	50V
C1152	1-124-589-11	ELECT	47uF	20%	16V
C1153	1-162-282-31	CERAMIC	100PF	10%	50V
C1154	1-124-257-00	ELECT	2.2uF	20%	50V
C1155	1-124-464-11	ELECT	0.22uF	20%	50V
C1156	1-136-161-00	FILM	0.047uF	5%	50V
C1157	1-136-155-00	FILM	0.015uF	5%	50V
C1158	1-136-155-00	FILM	0.015uF	5%	50V
C1159	1-130-480-00	MYLAR	0.0056uF	5%	50V
C1160	1-161-327-00	CERAMIC	0.0033uF	20%	16V
C1161	1-136-155-00	FILM	0.015uF	5%	50V
C1162	1-136-157-00	FILM	0.022uF	5%	50V
C1163	1-136-153-00	FILM	0.01uF	5%	50V
C1164	1-161-377-00	CERAMIC	0.0047uF	20%	16V
C1165	1-124-257-00	ELECT	2.2uF	20%	50V
C1173	1-162-286-31	CERAMIC	220PF	10%	50V
C1181	1-162-215-31	CERAMIC	47PF	5%	50V
C1182	1-162-215-31	CERAMIC	47PF	5%	50V
C1197	1-161-379-00	CERAMIC	0.01uF	20%	25V

Ref. No.	Part No.	Description	Remark
		< CONNECTOR >	
* CN601	1-568-830-11	SOCKET, CONNECTOR 11P	
CN1101	1-568-802-11	SOCKET, CONNECTOR 19P	
		< DIODE >	
D601	8-719-987-63	DIODE 1N4148M	
D602	8-719-010-26	DIODE UZ-3.9BSB	
D603	8-719-987-63	DIODE 1N4148M	
D604	8-719-987-63	DIODE 1N4148M	
D611	8-719-987-63	DIODE 1N4148M	
D612	8-719-987-63	DIODE 1N4148M	
D613	8-719-987-63	DIODE 1N4148M	
D614	8-719-987-63	DIODE 1N4148M	
D618	8-719-987-63	DIODE 1N4148M	
D621	8-719-987-63	DIODE 1N4148M (IT)	
D625	8-719-987-63	DIODE 1N4148M	
D641	8-719-200-82	DIODE 11ES2	
D1130	8-719-302-45	LED SEL1210S (VIDEO)	
D1131	8-719-302-45	LED SEL1210S (CD)	
D1132	8-719-302-45	LED SEL1210S (PHONO)	
D1133	8-719-302-45	LED SEL1210S (TUNER)	
D1134	8-719-302-45	LED SEL1210S (TAPE)	
D1145	8-719-301-39	LED SEL2210S-D (VOLUME)	
D1151	8-719-987-63	DIODE 1N4148M	
D1152	8-719-987-63	DIODE 1N4148M	
D1153	8-719-987-63	DIODE 1N4148M	
		< FILTER >	
FL601	1-519-711-11	INDICATOR TUBE, FLUORESCENT	
		< IC >	
IC601	8-759-053-97	IC uPD75212ACW-A2	
IC602	8-749-920-83	IC GP1U52XB	
IC1101	8-759-634-51	IC M5218AP	
IC1102	8-759-634-51	IC M5218AP	
IC1103	8-759-820-62	IC LB1639	
IC1104	8-759-916-12	IC SN74HC00AN	
		< COIL >	
L601	1-410-521-11	INDUCTOR 100uH	
		< TRANSISTOR >	
Q601	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q602	8-729-900-80	TRANSISTOR DTC114ES	
Q1101	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q1102	8-729-141-26	TRANSISTOR 2SC3622A-LK	
Q1121	8-729-900-36	TRANSISTOR DTC124ES	

Ref. No.	Part No.	Description				Remark
Q1122	8-729-119-76	TRANSISTOR	2SA1175-HFE			
Q1136	8-729-900-36	TRANSISTOR	DTC124ES			
Q1138	8-729-900-36	TRANSISTOR	DTC124ES			
Q1141	8-729-900-63	TRANSISTOR	DTA124ES			
Q1143	8-729-900-80	TRANSISTOR	DTC114ES			
Q1144	8-729-900-80	TRANSISTOR	DTC114ES			
Q1145	8-729-900-61	TRANSISTOR	DTA114ES			
Q1151	8-729-119-78	TRANSISTOR	2SC2785-HFE			
Q1152	8-729-141-26	TRANSISTOR	2SC3622A-LK			
		< RESISTOR >				
R601	1-249-429-11	CARBON	10K	5%	1/4W	
R602	1-249-429-11	CARBON	10K	5%	1/4W	
R603	1-249-423-11	CARBON	3.3K	5%	1/4W	
R604	1-249-437-11	CARBON	47K	5%	1/4W	
R605	1-249-433-11	CARBON	22K	5%	1/4W	
R606	1-249-433-11	CARBON	22K	5%	1/4W	
R607	1-249-439-11	CARBON	68K	5%	1/4W	
R608	1-249-417-11	CARBON	1K	5%	1/4W	
R609	1-249-405-11	CARBON	100	5%	1/4W	
R610	1-249-429-11	CARBON	10K	5%	1/4W	
R611	1-249-437-11	CARBON	47K	5%	1/4W	
R612	1-249-417-11	CARBON	1K	5%	1/4W	
R621	1-249-433-11	CARBON	22K	5%	1/4W	
R622	1-249-433-11	CARBON	22K	5%	1/4W	
R623	1-249-433-11	CARBON	22K	5%	1/4W	
R624	1-249-433-11	CARBON	22K	5%	1/4W	
R641	1-249-417-11	CARBON	1K	5%	1/4W	
R1101	1-249-441-11	CARBON	100K	5%	1/4W	
R1102	1-249-417-11	CARBON	1K	5%	1/4W	
R1103	1-249-431-11	CARBON	15K	5%	1/4W	
R1104	1-249-441-11	CARBON	100K	5%	1/4W	
R1105	1-249-433-11	CARBON	22K	5%	1/4W	
R1106	1-249-424-11	CARBON	3.9K	5%	1/4W	
R1107	1-249-441-11	CARBON	100K	5%	1/4W	
R1108	1-249-427-11	CARBON	6.8K	5%	1/4W	
R1109	1-249-412-11	CARBON	390	5%	1/4W	
R1110	1-249-431-11	CARBON	15K	5%	1/4W	
R1111	1-249-439-11	CARBON	68K	5%	1/4W	
R1112	1-249-433-11	CARBON	22K	5%	1/4W	
R1113	1-249-431-11	CARBON	15K	5%	1/4W	
R1114	1-249-429-11	CARBON	10K	5%	1/4W	
R1115	1-249-429-11	CARBON	10K	5%	1/4W	
R1116	1-247-852-11	CARBON	7.5K	5%	1/4W	
R1117	1-247-852-11	CARBON	7.5K	5%	1/4W	
R1118	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1119	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1120	1-249-423-11	CARBON	3.3K	5%	1/4W	
R1121	1-249-423-11	CARBON	3.3K	5%	1/4W	

Ref. No.	Part No.	Description				Remark
R1122	1-247-887-00	CARBON	220K	5%	1/4W	
R1123	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1124	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1125	1-249-433-11	CARBON	22K	5%	1/4W	
R1130	1-249-412-11	CARBON	390	5%	1/4W	
R1132	1-249-412-11	CARBON	390	5%	1/4W	
R1133	1-249-412-11	CARBON	390	5%	1/4W	
R1135	1-249-433-11	CARBON	22K	5%	1/4W	
R1143	1-249-433-11	CARBON	22K	5%	1/4W	
R1145	1-249-412-11	CARBON	390	5%	1/4W	
R1149	1-249-429-11	CARBON	10K	5%	1/4W	
R1151	1-249-441-11	CARBON	100K	5%	1/4W	
R1152	1-249-417-11	CARBON	1K	5%	1/4W	
R1154	1-249-441-11	CARBON	100K	5%	1/4W	
R1155	1-249-433-11	CARBON	22K	5%	1/4W	
R1156	1-249-424-11	CARBON	3.9K	5%	1/4W	
R1157	1-249-441-11	CARBON	100K	5%	1/4W	
R1158	1-249-427-11	CARBON	6.8K	5%	1/4W	
R1159	1-249-412-11	CARBON	390	5%	1/4W	
R1160	1-249-431-11	CARBON	15K	5%	1/4W	
R1161	1-249-439-11	CARBON	68K	5%	1/4W	
R1162	1-249-433-11	CARBON	22K	5%	1/4W	
R1163	1-249-431-11	CARBON	15K	5%	1/4W	
R1164	1-249-429-11	CARBON	10K	5%	1/4W	
R1165	1-249-429-11	CARBON	10K	5%	1/4W	
R1166	1-247-852-11	CARBON	7.5K	5%	1/4W	
R1167	1-247-852-11	CARBON	7.5K	5%	1/4W	
R1168	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1169	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1170	1-249-423-11	CARBON	3.3K	5%	1/4W	
R1171	1-249-423-11	CARBON	3.3K	5%	1/4W	
R1172	1-247-887-00	CARBON	220K	5%	1/4W	
R1173	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1174	1-249-425-11	CARBON	4.7K	5%	1/4W	

< VARIABLE RESISTOR >

RV1101	1-241-353-11	RES, VAR, CARBON	100K/100K	(SURROUND)
RV1102	1-241-353-11	RES, VAR, CARBON	100K/100K	(DBFB)
RV1103	1-241-351-11	RES, VAR, SLIDE	100K/100K	(100Hz)
RV1104	1-241-351-11	RES, VAR, SLIDE	100K/100K	(330Hz)
RV1105	1-241-351-11	RES, VAR, SLIDE	100K/100K	(1KHz)
RV1106	1-241-351-11	RES, VAR, SLIDE	100K/100K	(3.3KHz)
RV1107	1-241-351-11	RES, VAR, SLIDE	100K/100K	(10KHz)
RV1108	1-241-352-11	RES, VAR, CARBON	100K/100K	(BALANCE)

< SWITCH >

S601	1-554-303-21	SWITCH, TACTILE (1)
S602	1-554-303-21	SWITCH, TACTILE (2)

PANEL VOL H.P. POWER SW

Ref.No.	Part No.	Description			Remark
S603	1-554-303-21	SWITCH, TACTILE (3)			
S604	1-554-303-21	SWITCH, TACTILE (4)			
S605	1-554-303-21	SWITCH, TACTILE (5)			
S606	1-554-303-21	SWITCH, TACTILE (6)			
S607	1-554-303-21	SWITCH, TACTILE (7)			
S608	1-554-303-21	SWITCH, TACTILE (8)			
S609	1-554-303-21	SWITCH, TACTILE (9)			
S610	1-554-303-21	SWITCH, TACTILE (0)			
S611	1-554-303-21	SWITCH, TACTILE (SHIFT)			
S612	1-554-303-21	SWITCH, TACTILE (BAND SELECT)			
S613	1-554-303-21	SWITCH, TACTILE (ST/MUTE)			
S614	1-554-303-21	SWITCH, TACTILE (DUAL MODE TUNING +)			
S615	1-554-303-21	SWITCH, TACTILE (DUAL MODE TUNING -)			
S619	1-554-303-21	SWITCH, TACTILE (MEMORY)			
S636	1-554-303-21	SWITCH, TACTILE (TAPE)			
S637	1-554-303-21	SWITCH, TACTILE (CD)			
S638	1-554-303-21	SWITCH, TACTILE (TUNER)			
S639	1-554-303-21	SWITCH, TACTILE (PHONO)			
S640	1-554-303-21	SWITCH, TACTILE (VIDEO)			
		< CRYSTAL >			
X601	1-567-775-11	VIBRATOR, CERAMIC			
**********					
*	1-641-706-11	VOL BOARD			
		*********			
		< CAPACITOR >			
C1120	1-161-379-00	CERAMIC	0.01uF	20%	25V
		< VARIABLE RESISTOR >			
RV1109	1-241-350-11	RES, VAR, CARBON 100K/100K (VOLUME)			
**********					
*	1-641-707-11	H.P. BOARD			
		**********			
		< CAPACITOR >			
C1237	1-162-282-31	CERAMIC	100PF	10%	50V (IT)
C1238	1-162-282-31	CERAMIC	100PF	10%	50V (IT)
		< CONNECTOR >			
CNJ12011	-691-003-21	JACK, LARGE TYPE			
**********					
*	1-641-708-11	POWER BOARD			
		**********			
	1-533-217-31	HOLDER, FUSE			
		< CAPACITOR >			
C1301	1-161-744-00	CERAMIC	0.01uF		400V
C1314	1-124-122-11	ELECT	100uF	20%	50V
C1315	1-124-927-11	ELECT	4.7uF	20%	100V
C1316	1-124-910-11	ELECT	47uF	20%	50V
		< CONNECTOR >			
* CN1301	1-564-509-11	PLUG, CONNECTOR 6P			
CN1302	1-506-469-11	CONNECTOR	4P, MALE		
* CN1350	1-580-230-11	PIN, CONNECTOR (PC BOARD) 3P			
		< DIODE >			
D1307	8-719-002-60	DIODE	UZL-33L		
D1309	8-719-014-66	DIODE	UZP-5.6B		
D1311	8-719-200-82	DIODE	11ES2		
		< TRANSISTOR >			
Q1301	8-729-141-83	TRANSISTOR	2SB1094-LK		
		< RESISTOR >			
R1303	1-249-421-11	CARBON	2.2K	5%	1/4W
R1304	1-249-425-11	CARBON	4.7K	5%	1/4W
**********					
*	1-641-709-11	SW BOARD			
		********			
		< CAPACITOR >			
C701	1-124-903-11	ELECT	1uF	20%	50V
		< CONNECTOR >			
* CNJ701	1-568-834-11	SOCKET, CONNECTOR 15P			
		< TRANSISTOR >			
Q701	8-729-900-89	TRANSISTOR	DTC144ES		
Q702	8-729-900-89	TRANSISTOR	DTC144ES		
Q703	8-729-900-89	TRANSISTOR	DTC144ES		
		< RESISTOR >			
R701	1-249-417-11	CARBON	1K	5%	1/4W
R702	1-249-437-11	CARBON	47K	5%	1/4W
R703	1-249-424-11	CARBON	3.9K	5%	1/4W
R704	1-249-427-11	CARBON	6.8K	5%	1/4W
R705	1-249-421-11	CARBON	2.2K	5%	1/4W
R706	1-249-416-11	CARBON	820	5%	1/4W
R707	1-249-423-11	CARBON	3.3K	5%	1/4W

SW POWER AMP

Ref.No.	Part No.	Description				Remark
		< SWITCH >				
S701	1-572-994-11	SWITCH, PUSH (3 KEY) (TAPE SELECT/DUBBING SPEED/DOLBY NR)				
**********						
*	A-4345-905-A	POWER AMP BOARD, COMPLETE (AEP, UK)				
*	A-4347-082-A	POWER AMP BOARD, COMPLETE (IT)				
		**********				
		< CAPACITOR >				
C1201	1-124-257-00	ELECT	2.2uF	20%	50V	
C1202	1-162-286-31	CERAMIC	220PF	10%	50V	(AEP, UK)
C1202	1-162-290-31	CERAMIC	470PF	10%	50V	(IT)
C1203	1-162-286-31	CERAMIC	220PF	10%	50V	(AEP, UK)
C1203	1-162-290-31	CERAMIC	470PF	10%	50V	(IT)
C1204	1-124-477-11	ELECT	47uF	20%	25V	
C1205	1-124-910-11	ELECT	47uF	20%	50V	
C1206	1-124-122-11	ELECT	100uF	20%	50V	
C1207	1-136-165-00	FILM	0.1uF	5%	50V	
C1208	1-126-233-11	ELECT	22uF	20%	50V	
C1209	1-136-165-00	FILM	0.1uF	5%	50V	
C1210	1-136-163-00	FILM	0.068uF	5%	50V	
C1211	1-136-163-00	FILM	0.068uF	5%	50V	
C1220	1-124-910-11	ELECT	47uF	20%	50V	
C1230	1-161-494-00	CERAMIC	0.022uF		25V	(IT)
C1231	1-161-494-00	CERAMIC	0.022uF		25V	(IT)
C1232	1-161-494-00	CERAMIC	0.022uF		25V	(IT)
C1233	1-161-494-00	CERAMIC	0.022uF		25V	(IT)
C1251	1-124-257-00	ELECT	2.2uF	20%	50V	
C1252	1-162-286-31	CERAMIC	220PF	10%	50V	(AEP, UK)
C1252	1-162-290-31	CERAMIC	470PF	10%	50V	(IT)
C1253	1-162-286-31	CERAMIC	220PF	10%	50V	(AEP, UK)
C1253	1-162-290-31	CERAMIC	470PF	10%	50V	(IT)
C1254	1-124-477-11	ELECT	47uF	20%	25V	
C1255	1-124-910-11	ELECT	47uF	20%	50V	
C1256	1-124-122-11	ELECT	100uF	20%	50V	
C1257	1-136-165-00	FILM	0.1uF	5%	50V	
C1260	1-136-163-00	FILM	0.068uF	5%	50V	
C1261	1-136-163-00	FILM	0.068uF	5%	50V	
C1280	1-161-494-00	CERAMIC	0.022uF		25V	(IT)
		< DIODE >				
D1201	8-719-987-63	DIODE 1N4148M				
D1251	8-719-987-63	DIODE 1N4148M				
		< IC >				
IC1201	8-749-920-19	IC STK4122MK2				

Ref.No.	Part No.	Description				Remark
		< COIL >				
* L1201	1-420-872-00	COIL, AIR CORE				
* L1251	1-420-872-00	COIL, AIR CORE				
		< TRANSISTOR >				
Q1201	8-729-140-84	TRANSISTOR 2SC1841-PAFAEA				
Q1202	8-729-900-80	TRANSISTOR DTC114ES				
Q1203	8-729-119-78	TRANSISTOR 2SC2785-HFE				
Q1251	8-729-140-84	TRANSISTOR 2SC1841-PAFAEA				
		< RESISTOR >				
R1201	1-249-417-11	CARBON	1K	5%	1/4W	
R1202	1-249-438-11	CARBON	56K	5%	1/4W	
R1203	1-249-417-11	CARBON	1K	5%	1/4W	
R1204	1-249-438-11	CARBON	56K	5%	1/4W	
R1205	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1206	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1207	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1208	1-249-425-11	CARBON	4.7K	5%	1/4W	
⚠R1209	1-212-881-11	FUSIBLE	100	5%	1/4W	F
⚠R1210	1-217-151-00	RES, METAL PLATE			0.22	
R1211	1-249-417-11	CARBON	1K	5%	1/4W	
R1212	1-249-431-11	CARBON	15K	5%	1/4W	
R1213	1-249-441-11	CARBON	100K	5%	1/4W	
R1214	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1215	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1216	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1217	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1218	1-249-397-11	CARBON	22	5%	1/4W	
R1219	1-249-397-11	CARBON	22	5%	1/4W	
R1220	1-249-397-11	CARBON	22	5%	1/4W	
R1221	1-249-397-11	CARBON	22	5%	1/4W	
R1227	1-249-429-11	CARBON	10K	5%	1/4W	
R1228	1-247-881-00	CARBON	120K	5%	1/4W	
R1229	1-249-439-11	CARBON	68K	5%	1/4W	
R1230	1-249-439-11	CARBON	68K	5%	1/4W	
R1231	1-249-417-11	CARBON	1K	5%	1/4W	
R1232	1-249-428-11	CARBON	8.2K	5%	1/4W	
R1238	1-249-433-11	CARBON	22K	5%	1/4W	
R1239	1-249-426-11	CARBON	5.6K	5%	1/4W	
R1251	1-249-417-11	CARBON	1K	5%	1/4W	
R1252	1-249-438-11	CARBON	56K	5%	1/4W	
R1253	1-249-417-11	CARBON	1K	5%	1/4W	
R1254	1-249-438-11	CARBON	56K	5%	1/4W	
R1255	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1256	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1257	1-249-425-11	CARBON	4.7K	5%	1/4W	
R1258	1-249-425-11	CARBON	4.7K	5%	1/4W	

POWER AMP TC MAIN

Ref.No.	Part No.	Description			Remark
⚠R1259	1-212-881-11	FUSIBLE	100	5%	1/4W F
⚠R1260	1-217-151-00	RES, METAL PLATE			0.22
R1261	1-249-417-11	CARBON	1K	5%	1/4W
R1262	1-249-431-11	CARBON	15K	5%	1/4W
R1263	1-249-441-11	CARBON	100K	5%	1/4W
R1268	1-249-397-11	CARBON	22	5%	1/4W
R1269	1-249-397-11	CARBON	22	5%	1/4W
R1270	1-249-397-11	CARBON	22	5%	1/4W
R1271	1-249-397-11	CARBON	22	5%	1/4W

****

* A-4345-901-A TC MAIN BOARD, COMPLETE
****

1-535-995-11 JUMPER, FILM (WITH TERMINAL)
7-685-646-79 SCREW +BVTP 3X8 TYPE2 N-S

< CAPACITOR >

C400	1-162-289-31	CERAMIC	390PF	10%	50V
C401	1-136-157-00	FILM	0.022uF	5%	50V
C402	1-124-767-00	ELECT	2.2uF	20%	50V
C403	1-124-443-00	ELECT	100uF	20%	10V
C404	1-162-289-31	CERAMIC	390PF	10%	50V
C405	1-136-157-00	FILM	0.022uF	5%	50V
C406	1-124-767-00	ELECT	2.2uF	20%	50V
C407	1-124-443-00	ELECT	100uF	20%	10V
C408	1-130-479-00	MYLAR	0.0047uF	5%	50V
C409	1-162-289-31	CERAMIC	390PF	10%	50V
C410	1-124-903-11	ELECT	1uF	20%	50V
C411	1-124-925-11	ELECT	2.2uF	20%	100V
C413	1-124-472-11	ELECT	470uF	20%	10V
C414	1-131-587-11	TANTALUM	0.68uF	5%	35V
C415	1-124-925-11	ELECT	2.2uF	20%	100V
C416	1-124-927-11	ELECT	4.7uF	20%	100V
C417	1-124-902-00	ELECT	0.47uF	20%	50V
C418	1-124-907-11	ELECT	10uF	20%	50V
C419	1-124-907-11	ELECT	10uF	20%	50V
C420	1-124-907-11	ELECT	10uF	20%	50V
C421	1-162-284-31	CERAMIC	150PF	10%	50V
C422	1-136-273-91	FILM	75PF	5%	630V
C423	1-136-271-00	FILM	56PF	5%	630V
C424	1-162-280-31	CERAMIC	82PF	10%	50V
C441	1-162-282-31	CERAMIC	100PF	10%	50V
C442	1-164-159-11	CERAMIC	0.1uF		50V
C443	1-124-903-11	ELECT	1uF	20%	50V
C446	1-162-282-31	CERAMIC	100PF	10%	50V
C500	1-162-289-31	CERAMIC	390PF	10%	50V
C501	1-136-157-00	FILM	0.022uF	5%	50V
C502	1-124-767-00	ELECT	2.2uF	20%	50V
C503	1-124-443-00	ELECT	100uF	20%	10V
C504	1-162-289-31	CERAMIC	390PF	10%	50V
C505	1-136-157-00	FILM	0.022uF	5%	50V
C506	1-124-767-00	ELECT	2.2uF	20%	50V
C507	1-124-443-00	ELECT	100uF	20%	10V
C508	1-130-479-00	MYLAR	0.0047uF	5%	50V
C509	1-162-289-31	CERAMIC	390PF	10%	50V
C511	1-124-925-11	ELECT	2.2uF	20%	100V
C513	1-124-472-11	ELECT	470uF	20%	10V
C514	1-131-587-11	TANTALUM	0.68uF	5%	35V
C515	1-124-925-11	ELECT	2.2uF	20%	100V
C516	1-124-927-11	ELECT	4.7uF	20%	100V
C517	1-124-902-00	ELECT	0.47uF	20%	50V
C518	1-124-907-11	ELECT	10uF	20%	50V
C520	1-124-907-11	ELECT	10uF	20%	50V
C521	1-162-284-31	CERAMIC	150PF	10%	50V
C522	1-136-273-91	FILM	75PF	5%	630V
C523	1-136-271-00	FILM	56PF	5%	630V
C524	1-162-280-31	CERAMIC	82PF	10%	50V
C525	1-136-562-11	FILM	0.0082uF	5%	630V
C526	1-130-482-00	MYLAR	0.0082uF	5%	50V
C527	1-124-925-11	ELECT	2.2uF	20%	100V
C528	1-130-482-00	MYLAR	0.0082uF	5%	50V
C529	1-130-478-00	MYLAR	0.0039uF	5%	50V
C530	1-130-478-00	MYLAR	0.0039uF	5%	50V
C531	1-124-902-00	ELECT	0.47uF	20%	50V
C532	1-124-925-11	ELECT	2.2uF	20%	100V
C533	1-124-556-11	ELECT	2200uF	20%	16V
C534	1-124-120-11	ELECT	220uF	20%	25V
C535	1-124-927-11	ELECT	4.7uF	20%	100V
C536	1-124-903-11	ELECT	1uF	20%	50V
C540	1-124-472-11	ELECT	470uF	20%	10V
C541	1-162-282-31	CERAMIC	100PF	10%	50V
C542	1-164-159-11	CERAMIC	0.1uF		50V
C546	1-162-282-31	CERAMIC	100PF	10%	50V
C560	1-124-472-11	ELECT	470uF	20%	10V

< CONNECTOR >

* CN400	1-564-506-11	PLUG, CONNECTOR 3P
* CN401	1-564-509-11	PLUG, CONNECTOR 6P
* CN402	1-564-505-11	PLUG, CONNECTOR 2P
* CN405	1-560-061-00	PIN, CONNECTOR 3P
* CN406	1-564-505-11	PLUG, CONNECTOR 2P
* CN407	1-560-060-00	PIN, CONNECTOR 2P
* CN410	1-564-506-11	PLUG, CONNECTOR 3P
* CN411	1-564-508-11	PLUG, CONNECTOR 5P
* CN412	1-564-706-11	PIN, CONNECTOR (SMALL TYPE) 4P

TC MAIN

Ref. No.	Part No.	Description				Remark
		< DIODE >				
D500	8-719-987-63	DIODE	1N4148M			
D501	8-719-987-63	DIODE	1N4148M			
D502	8-719-987-63	DIODE	1N4148M			
D503	8-719-987-63	DIODE	1N4148M			
D504	8-719-987-63	DIODE	1N4148M			
D505	8-719-987-63	DIODE	1N4148M			
D506	8-719-987-63	DIODE	1N4148M			
D507	8-719-987-63	DIODE	1N4148M			
		< IC >				
IC400	8-759-111-44	IC	uPC4570C-1			
IC401	8-759-111-44	IC	uPC4570C-1			
IC402	8-759-000-49	IC	MC14066BCP			
IC403	8-752-057-21	IC	CXA1100P			
IC404	8-752-038-02	IC	CXA1198AP			
IC501	8-759-140-11	IC	uPD4011BC			
IC502	8-759-040-01	IC	MC14001BCP			
IC503	8-759-140-11	IC	uPD4011BC			
IC515	8-759-604-86	IC	M5F7807L			
IC516	8-759-604-90	IC	M5F7907L			
		< COIL >				
L400	1-410-780-11	INDUCTOR	27mH			
L500	1-410-780-11	INDUCTOR	27mH			
		< TRANSISTOR >				
Q400	8-729-900-89	TRANSISTOR	DTC144ES			
Q401	8-729-900-89	TRANSISTOR	DTC144ES			
Q402	8-729-119-78	TRANSISTOR	2SC2785-HFE			
Q403	8-729-119-78	TRANSISTOR	2SC2785-HFE			
Q500	8-729-900-89	TRANSISTOR	DTC144ES			
Q502	8-729-119-78	TRANSISTOR	2SC2785-HFE			
Q503	8-729-119-78	TRANSISTOR	2SC2785-HFE			
Q504	8-729-194-57	TRANSISTOR	2SC945-P			
Q505	8-729-194-57	TRANSISTOR	2SC945-P			
Q506	8-729-281-52	TRANSISTOR	2SC1815-Y			
Q507	8-729-900-61	TRANSISTOR	DTA114ES			
Q508	8-729-900-80	TRANSISTOR	DTC114ES			
Q509	8-729-119-76	TRANSISTOR	2SA1175-HFE			
Q511	8-729-900-65	TRANSISTOR	DTA144ES			
Q512	8-729-900-89	TRANSISTOR	DTC144ES			
		< RESISTOR >				
R415	1-215-460-00	METAL		43K	1%	1/6W
R417	1-249-437-11	CARBON		47K	5%	1/4W
R418	1-247-838-00	CARBON		2K	5%	1/4W
R431	1-249-435-11	CARBON		33K	5%	1/4W
R432	1-247-868-11	CARBON		36K	5%	1/4W
R433	1-247-883-00	CARBON		150K	5%	1/4W
R436	1-249-437-11	CARBON		47K	5%	1/4W
R437	1-249-437-11	CARBON		47K	5%	1/4W
R438	1-247-874-11	CARBON		62K	5%	1/4W
R439	1-249-440-11	CARBON		82K	5%	1/4W
R441	1-247-882-11	CARBON		130K	5%	1/4W
R442	1-249-435-11	CARBON		33K	5%	1/4W
R443	1-247-868-11	CARBON		36K	5%	1/4W
R446	1-249-438-11	CARBON		56K	5%	1/4W
R450	1-247-868-11	CARBON		36K	5%	1/4W
R451	1-247-872-11	CARBON		51K	5%	1/4W
R452	1-249-437-11	CARBON		47K	5%	1/4W
R453	1-247-881-00	CARBON		120K	5%	1/4W
R517	1-249-437-11	CARBON		47K	5%	1/4W
R518	1-247-838-00	CARBON		2K	5%	1/4W
R527	1-249-441-11	CARBON		100K	5%	1/4W
R532	1-249-393-11	CARBON		10	5%	1/4W
R538	1-249-385-11	CARBON		2.2	5%	1/6W
R539	1-249-392-11	CARBON		8.2	5%	1/4W
R540	1-249-392-11	CARBON		8.2	5%	1/4W
		< VARIABLE RESISTOR >				
RV400	1-230-496-11	RES, ADJ, CARBON	10K			
RV401	1-230-496-11	RES, ADJ, CARBON	10K			
RV402	1-230-496-11	RES, ADJ, CARBON	10K			
RV403	1-230-499-11	RES, ADJ, CARBON	100K			
RV500	1-230-496-11	RES, ADJ, CARBON	10K			
RV501	1-230-496-11	RES, ADJ, CARBON	10K			
RV502	1-230-496-11	RES, ADJ, CARBON	10K			
RV503	1-230-499-11	RES, ADJ, CARBON	100K			
RV504	1-230-495-11	RES, ADJ, CARBON	2.2K			
RV505	1-230-495-11	RES, ADJ, CARBON	2.2K			
		< RELAY >				
RY400	1-515-614-11	RELAY				
		< TRANSFORMER >				
T500	1-433-349-11	TRANSFORMER, BIAS OSCILLATION				
**********						
		MISCELLANEOUS				
		**********				
11	1-590-459-11	WIRE, FLAT TYPE (11 CORE)				
12	1-590-578-11	WIRE, FLAT TYPE (19 CORE)				
⚠59	1-690-708-11	CORD (WITH CONNECTOR)				
⚠CNP13011	-575-651-61	CORD, POWER (AEP, IT)				
⚠CNP13011	-575-652-21	CORD, POWER (UK)				
⚠F1301	1-532-237-00	FUSE, TIME LAG (3.15A)				
⚠F1302	1-532-237-00	FUSE, TIME LAG (3.15A)				

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Ref. No.	Part No.	Description	Remark
⚠F1303	1-532-203-00	FUSE (2.0A)	
⚠F1304	1-532-203-00	FUSE (2.0A)	
HE1	1-543-673-11	HEAD, MAGNETIC (ERASE) (DECK B)	
HP1	1-543-319-11	HEAD, MAGNETIC (PB) (DECK A)	
HRP1	1-543-319-11	HEAD, MAGNETIC (REC/PB) (DECK B)	
M1	X-3362-377-1	MOTOR (WH) ASSY	
⚠S1301	1-572-267-61	SWITCH, PUSH (AC POWER) (1 KEY)	
⚠T1301	1-450-308-11	TRANSFORMER, POWER (AEP, IT)	
⚠T1301	1-450-743-11	TRANSFORMER, POWER (UK)	

****

ACCESSORIES & PACKING MATERIALS

****

	1-465-962-11	COMMANDER (STANDARD TYPE) (RM-S171)
	1-501-369-11	ANTENNA (LEAD)
	1-501-374-11	ANTENNA, LOOP
	3-754-598-11	MANUAL, INSTRUCTION (ENGLISH, FRENCH, SPANISH, PORTUGUESE) (AEP)
	3-754-598-41	MANUAL, INSTRUCTION (GERMAN, DUTCH, SWEDISH, ITALIAN) (AEP, IT)
	4-921-934-01	SHEET, PROTECTION
*	4-949-428-01	CUSHION (UK)
*	4-949-428-11	CUSHION
*	4-949-992-01	INDIVIDUAL CARTON (AEP, IT)

****

HARDWARE LIST

#1	7-685-646-79	SCREW +BVTP 3X8 TYPE2 N-S
#2	7-685-133-19	SCREW +P 2.6X6 TYPE2
#3	7-621-775-20	SCREW +B 2.6X5
#4	7-685-135-19	SCREW +BTP 2.6X10 TYPE2 N-S
#5	7-685-103-19	SCREW +P 2X5 TYPE2 NON-SLIT
#6	7-623-921-01	RING, RETAINING, CAPSTAN
#7	7-682-547-04	SCREW +BVTT 3X6 (S)
#8	7-688-001-01	W 2, SMALL
#9	7-621-849-00	SCREW, TAPPING
#10	7-685-650-79	SCREW +BVTP 3X16 TYPE2 IT-3

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

9-956-931-11

Sony Corporation
Audio Group

English
92A1860-1
Printed in Japan
©1992.1
Published by Customer Relations and Service Group